




display mounting

INSTRUCTIONS

FRENCH CLEAT - 2 CLEATS


1

Remove display from crate and lay it face down on a clean, soft surface.



2

Remove the french cleats by untaping or unscrewing.



3

Measure to find the center of the display and mark the center (on backside).



4

Measure from the center of the display to the top cleat area & measure the distance between cleats.



5

Typically, the center of your display will be 57" from the floor - mark the wall where you want the center.



6

Measure from the center mark to where the top of the cleat will be (step 4) and mark the wall.



PIR

PARTNERS IN RECOGNITION, INC.

405 S. Main St., Fort Loramie, OH 45845 | 937.420.2150 | gopir.com

display MOUNTING

7

Drill pilot holes in your cleat; the number of holes will depend on the size of the cleat and display.



8

Place cleat on wall where you marked its location and anchor with appropriate hardware.



9

Level the cleat and add additional fasteners.



10

Measure down & mark your wall the distance you measured between cleats (step 4).



11

Place second cleat on wall where you marked its location and anchor with appropriate hardware.



12

Use level to anchor the balance.



13

Lift the display to where the pockets are above the cleats; press the display against the wall and let it slide down onto the cleats.



PIR
PARTNERS IN RECOGNITION, INC.